

Technical datasheet

Trailer, Oil Handling & Transport System

Introduction

For easy oil change, onshore the SOCOTFlex+ is positioned in a van. A trailer unit is tensioned to the van.

The trailer carries 5 IBC and relevant pumping systems. Generator and transfer pumps are installed. Transfer pumps are provided with an engine starter.

A 6500W gasoline generator is mounted on the trailer to feed 3x400V to transfer pumps and electrical heating (not included in delivery).

Two transfer pumps are providing positive feeding pressure for gear oil and hydraulic oil to the SOCOTFlex+ unit.

The trailer bottom is protected with a drip tray of tarpaulin material and Velcro, adjustable when positioning tanks.

Sides and corners can be tilted or removed providing optimal access for load or off-load with forklift.

OTW item number.: 7000-127



Features

- Compact sizes make it easy to transport
- All-in-one onshore solution
- Independent work with generator
- Works in cool weather

Safety features

- Fully covering drip-tray
- Inner lashed for optimal clamping
- Trailer brakes

Capacity & performance

Trailer Type:	Open, Brenderup ATB 5420 Wide
Trailer Payload:	2846 kg
Option:	Heat blankets for tanks in trailer
Option:	Oil can be provided

Weight & dimensions

Outer measures:	L5440xB1860mm
Tare weight:	654 kg
Wheel dimensions:	R14", 2 axles